

ASSEMBLY OF TECHNICAL FABRIC COVERS FOR UNIVERSAL CLAMPS

RIGHT SIDE

1. Insert the hole onto the tip of the conical pin and slide it along the pin until it reaches the clamp, passing over the conical perimeter.

NOTE: The cover is made of elastic material. During assembly, it is necessary to pull it firmly to overcome the elastic resistance and facilitate insertion.



2. Grab the other end of the cover and pull it, passing it from the outside toward the inside and wrapping it around the clamp. Then, align the second hole with the tip of the pin and slide it along the pin until it reaches the clamp, passing over the conical perimeter.



LEFT SIDE: Repeat the same procedure on the left side, following the previously described steps.